

**PurpurLab**

is dedicated to meet customer needs.



# Color-Paste IND

Colourants for water-based industrial coatings















# Color-Paste IND – your choice for water-based industrial coatings.

Patented grinding media technology makes the difference.

## Main advantages

- Fast drying of coloured coatings
- Very good block resistance
- Maintains original hardness of applied films
- Compatibility in a broad range of 1K and 2K binders
- Excellent stability against flocculation
- Minor influence on gloss
- Exceptionally high coverage
- Outstanding resistance against chemicals
- No migration into solvent-borne top coat
- Easy-to-handle free flowing pigment preparations
- Due to narrow specifications fine for volumetric dosage
- Data base for automatic tinting system available

| Product Name   | Colour Index<br>Generic Name | Pigment Content<br>approx. [%] | Lightfastness<br>from 1 weak<br>to 8 superiour |
|--|------------------------------|--------------------------------|--|
|  Color-Paste IND Gelb 1036 BIS         | P.Y.155                      | 45                             | 6  |
|  Color-Paste IND Neutralgelb 1126 AZO  | P.Y.74                       | 49                             | 6  |
|  Color-Paste IND Ocker 1758 XAO      | P.Y.42                       | 62                             | 8  |
|  Color-Paste IND Reinorange 2047 DAR | P.O.62                       | 45                             | 7  |
|  Color-Paste IND Rot 3037 DPP        | P.R.254                      | 44                             | 7  |
|  Color-Paste IND Terracotta 3658 XFE | P.R.101                      | 73                             | 8  |
|  Color-Paste IND Magenta 4047 CHI    | P.R.122                      | 25                             | 7  |
|  Color-Paste IND Violett 4137 CAR    | P.V.23                       | 12                             | 7  |
|  Color-Paste IND Cyan 5147 PHT       | P.B.15:3                     | 36                             | 7  |
|  Color-Paste IND Grün 6047 CHL       | P.G.7                        | 40                             | 7  |
|  Color-Paste IND Schwarz 9058 CBA    | P.Bk.7                       | 34                             | 8  |
|  Color-Paste IND Weiss 9658 XAW      | P.W.6                        | 70                             | 8  |

The colour index data refers to the basic pigments. All information in this data sheet is based on our current knowledge and experience. It does not constitute a legally binding guarantee of certain properties or suitability for a specific application cannot be derived from it. Each user of our products must check their suitability for their specific purposes on their own responsibility.

This solvent-free pigment dispersions have been especially developed for the colouration of industrial coatings. The polymere core / shell grinding media guarantees an excellent quality of colour lacquers. The well-known performance of solvent-borne coatings is representable. Due to grinding

media technology the positive qualities known from conventional systems can be applied to water-based coatings. This aspect enables added quantities up to 25 % of the colour pastes while maintaining the desired technical and physical film qualities on surfaces like wood and plastic.

Version: 2.0

**PurpurLab – Dedicated Colour Solutions.**

PurpurLab GmbH · Kreuzauer Strasse 46 · D-52355 Düren  
Tel: +49 (0)2421/ 9900-8910 · Fax: +49 (0)2421/ 9900-8999  
Web: [www.purpurlab.de](http://www.purpurlab.de) · E-Mail: [ppl@purpurlab.de](mailto:ppl@purpurlab.de)

